


BF12M Breakdown

Boom, 160" Manual Fold



Ref #	Qty.	Part Number	Description
1	4	0438P	* Shaft Collar, 7/16"
2	2	33*TS	* Spring, Extension 1" x 8"
3	2	BF1210	* Boom mounting clip, 12' boom, black
4	1	BF1211	Boom center section
5	1	BF1212L	Boom wing, left
6	1	BF1212R	Boom wing, right
7	1	BF1212MOM	Owners Manual (Not Shown)
8	2	BF1213	Hinge bolt, 1/2-13 x 4 1/4"
9	2	BF1214	* Wing rest plate, 12' & 20' Booms
10	2	BF1215	* Rubber trim for 12' and 20' boom rest
11	2	BF1216	* 12' manual fold boom spacer block
12	4	CB14*134G5	* Bolt, Carriage 1/4-20 x 1-3/4" Gr 5
13	4	CB38*4G5	* Bolt, Carriage 3/8-16 x 4" Gr 5
14	6	CC5520	* Cap, Poly Square 1-1/4" x 14-20 Ga Blk
15	4	FN14	* Nut, Flange 1/4-20
16	4	FN38	* Nut, Flange 3/8-16
17	2	FW12	* Washer, Flat 1/2"
18	2	NNC12	* Nut, Nylon Lock 1/2-13

* HDK12 kit